



*solder the negative motor lead directly to the thick drain-D1 trace*

